

# VERMEC

ABN: 54 564 780 592

39 Dalton Street  
KIPPA-RING QLD 4021

Email: vermec@netspace.net.au

Ph: 07 3284 3733  
Fax: 07 3284 2733

Woodworking Supplies and Engineering

## VERMEC CHUCK

Code: CHU-501

注意：どの様な道具も危険なものです。使用者は怪我をしないよう十分注意して下さい。購入者は購入したものが自分の使用目的に合っているかどうか確認する責任があります。



1、同梱の爪をチャックのネジ穴に、付属のネジを使って軽く締め付けて下さい。爪には1から4の番号がふってあり、反時計方向に順番に取り付けるようになっています。ネジは軽く締め付けると中心位置に自動的に固定されます。爪が中心に固定されたら、8つのネジを完全に締め付けます。

注意：Vermecのチャックは6mmのネジを使っており、Vicmarcの爪など同等品は5mmなので、これらの爪を取り付ける場合は、ドリルで穴を広げる必要があります。

2、チャックのインサートを付属のTレンチを使って取り付けます。ゴミなど付いていないことを確認の上しっかり締め付けます。(写真1)

3、チャックを旋盤の主軸に取り付けて下さい。(写真2)

4、Tレンチを使って爪を開けたり締めたりして下さい。チャックにはストップピンが取り付けられているので、無理に爪を広げることはしないで下さい。(写真3)

5、センタースクリューは、小さい作品を固定するのに使い、爪で固定します。センタースクリューの肩を、爪を固定している台(バックジョー)で固定します。(写真4)

6、チャックに付いたゴミは取り除いて下さい。またオイルを定期的に塗って下さい。



写真1



写真3



写真2



写真4

Warranty - Vermec offer a 2 year warranty from date of purchase for faulty materials or workmanship. If chuck has been altered, repaired, modified, subject to misuse, negligence, accident or not used in accordance with instructions warranty will be void. Proof of purchase (sales receipt) must accompany warranty claim. Chuck must be returned to Vermec at purchaser's expense. Warranty does not cover costs or damages arising directly or indirectly from operation of this Vermec product.

NOW ON THE WEB AT WWW.VERMEC.COM